

The Homeowner's Guide: Basin Installation

SURFACE MOUNTED BASIN INSTALLATION GUIDE:

1. **CLEAN** - Ensure the base of your basin and vanity top are clean and free of dust, dirt and the surfaces are completely dry.
2. **CHECK** - Measure the basin and ensure it will fit correctly onto the vanity top.
3. **FIT** - The waste to the basin following the manufacturers details and ensure you do not over tighten the waste. Cracks that appear from the waste extending outwards are a sign that the waste has been over tightened and cracked your basin.
4. **APPLY** - Flexible bathroom fixative to the base of the basin, ensuring you do not put an excessive amount on and avoid applying it close to the outer edge or the waste. Excess fixative may seep out from under the basin once it has been fitted to the vanity top. Clean off any excess from the surfaces.
5. **PLACE** - The basin carefully on the vanity top and push down firmly.
6. **REMOVE** - Excess fixative.
7. **BEAD** - A thin run of clear silicone around the outer edge of the basin between the basin and the vanity top. This will avoid any liquid from seeping under the basin.
8. **REMOVE** - Excess silicone by carefully running a paddle pop stick or something similar to a credit card around the edge of the basin and vanity top to keep the silicone bead even and smooth as well as removing excess silicone.

