

The Homeowner's Guide: How to Measure & Ordering for a Bespoke Vanity

Measure Twice, Cast Once. > To ensure your custom piece fits perfectly into your architectural layout, please follow these measurement guidelines before entering your dimensions.

A. Defining Your Footprint (Length & Depth)

- **Length:** Measure the wall-to-wall distance if the vanity is "enclosed" (alcove), or the desired length of the top if it is "freestanding."
- **Depth:** Standard vanity depth is 460mm to 500mm. Ensure you allow for clearance of doors and drawers.
- **Pro Tip:** If your walls aren't perfectly square (common in older homes), provide the smallest dimension found to ensure the slab can slide into place.

B. The "Apron" or Facing (The Visible Edge)

- The Facing is the vertical drop that hides the cabinet or support structure.
- **Front Facing:** Required for all vanities.
- **Side Facings:** Required for any "exposed" ends. If your vanity sits in a corner, you only need one side facing. If it sits between two walls, you need zero side facings.
- Because our slabs are 25mm thick, your front and side facings must be a minimum of 25mm. From there, you may specify any height (e.g., 150mm) to create a bold, monolithic appearance.
- **Standard Height:** There is no real "Standard" height when you are looking at Custom. Our job is to create a customised vanity that is truly unique for you. We can work with your joinery to ensure the vanity top will suit your joinery.